

AirLink 7032 Gas Monitor Operator's Manual

Part Number: 71-0560 Revision: P3 Released: 1/17/24

RKI Instruments, Inc. www.rkiinstruments.com

Product Warranty

RKI Instruments, Inc. (Manufacturer) warrants its products to be free of defects in workmanship and materials—under normal use and service—for one year from the date of purchase from the manufacturer or from the product's authorized reseller.

The manufacturer is not liable (under this warranty) if its testing and examination disclose that the alleged defect in the product does not exist or was caused by the purchaser's (or any third party's) misuse, neglect, or improper installation, testing or calibrations. Any unauthorized attempt to repair or modify the product, or any other cause of damage beyond the range of the intended use, including damage by fire, lightning, water damage or other hazard, voids liability of the manufacturer.

Any repaired or replaced product or part has either a 90-day warranty or the remainder of the initial warranty period (whichever is longer).

Table of Contents

Chapter 1: Introduction
Overview
About the AirLink 7032 Gas Monitor 5
About this Manual
Specifications
Chapter 2: Internal Components
Chapter 3: Installation
Mounting the AirLink 7032 Gas Monitor
Wiring the AirLink 7032 Gas Monitor 12
Chapter 4: Startup and Operation 21
Power On/Off
Home Screen
Trend Chart
Real-Time Values
View Days Since Last Zero and Cal
Relay Indicators
Chapter 5: Channel Configuration Menu 29
Overview
Entering the Channel Configuration Menu
Editing Channel Settings
Changing the Date, Time, and Location
Exiting Setup Mode
Chapter 6: Advanced Configuration Menu 34
Overview
Editing Advanced Configuration Parameters
Chapter 7: Maintenance
Calibration Mode

Relay Test Mode	38
Troubleshooting	40
Chapter 9. Viewing USD Log Files	13
Chapter 6: viewing USB Log Files	43
Chapter 9: Parts List	47
Appendix A: Relay Operation	48
Appendix B: Introduction to 4-20 mA Current Loop Signals	50
Appendix C: RS-485 Modbus Output	52
Modbus Terms	52
Register Map	52

Chapter 1: Introduction

Overview

This chapter briefly describes the AirLink 7032 Gas Monitor. This chapter also describes the *AirLink 7032 Gas Monitor Operator's Manual* (this document). Table 1 at the end of this chapter lists the specifications for the AirLink 7032.

About the AirLink 7032 Gas Monitor

The AirLink 7032 is a hybrid monitor and data logger that supports either 32 AirLink sensor units or 64 AirLink sensor units depending on the configuration ordered. Either configuration can also be set up for 4, wired 4-20 mA input sensors in place of 4 AirLink sensors.

All channels can be configured to detect AirLink gas sensor assemblies. If desired, the last four channels (29-32 for 32-channel versions, and 60-64 for 64-channel versions) can be configured to accept a 4-20 mA signal. By default, all channels except the last four are configured for AirLink sensor assemblies. The last <u>four</u> channels are configured for wired sensor assemblies. Any channel can be turned "off", and any channel can be configured to any valid AirLink address, 1-255.

There are four 5 Amp relays with 4 Amp fuses. The fourth relay may be configured as a Fault relay. This Fault relay will activate if any Fault is generated by the monitor or if any sensor that the monitor is configured to monitor goes into Fault. The Fault relay is removed from any further configurable options from Channel Setup—leaving only three relays for each channel. All relays can be configured to be either latching or auto resetting. The relays can be configured with different set points for each channel.

An optional strobe and/or horn can be ordered. The strobe is installed on the top of the housing and is wired into the first relay. The horn is installed on the bottom of the housing and is wired into the second relay.

All relays have a 10% of value of hysteresis on the set points. This prevents the relays from rapidly switching on and off during a potentially jumpy gas sensor reading. Once the threshold value of a relay is reached, the relay is activated and the appropriate relay number is highlighted for the affected channel. The gas reading must decreases to 90% of the relay value to deactivate.

About this Manual

The *AirLink 7032 Gas Monitor Operator's Manual* uses the following conventions for notes, cautions, and warnings:

NOTE: Describes additional or critical information.

CAUTION: Describes potential damage to equipment.

WARNING: Describes potential danger that can result in injury or death.



Caution: refer to accompanying documentation



---- Vdc (DC voltage)

Specifications

Table 1 lists specifications for the AirLink 7032.

Table 1: AirLink 7032 Specifications

Input Power	120/240V ~ OR 22 - 26 V
Current Draw	300 mA max at 24 VDC (monitor without sensor assemblies)3A max (with sensor assemblies)
Operating Temperature	-20°F to 122°F (-28.9°C to 50°C)

Input Signal	 <u>52-channel AITLINK 7032</u> Up to 32 WireFree sensor assemblies OR Up to 28 WireFree sensor assemblies and up to 4 4-20 mA input sensor assemblies <u>64-channel AirLink 7032</u> Up to 64 WireFree sensor assemblies OR Up to 60 WireFree sensor assemblies and up to 4 4-20 mA input sensor assemblies 					
Output	 RS-485 Modbus Datalogging to USB drive					
Construction (housing)	Fiberglass with clear window (NEMA 4)					
Dimensions	14.97 in. H x 12.17 in. W x 6.56 in. D (38.02 cm H x 30.91 cm W x 16.66 cm D)					
Weight	12 lbs.					
Mounting	4 mounting feet (8" W x 14.38" T); 1/4" diameter max mounting bolt/screw size					
Display	7" resistive touchscreen					
Relays	 4 relays with 4A fuses SPDT, Form C (common, normally open, and normally closed contacts) 					
Radio Options	 2.4 GHz, ISM, 125 mW OR 900 MHz, 200 mW 					
G4 1 1 A	• Operator's manual (this document)					
Standard Accessory	• SD card with USB adapter					

Table 1: AirLink 7032 Specifications

Chapter 2: Internal Components

The inside of the AirLink 7032 contains the terminal board for wiring connections and the AC power supply (for AC versions). The back of the touchscreen module is visible and has an SD card with USB adapter installed on the back for datalogging.



Figure 1: Internal Components



Figure 2: Terminal Board

Chapter 3: Installation

Mounting the AirLink 7032 Gas Monitor

- 1. Select the mounting site. When you select the mounting site, consider the following factors:
 - Is an AC or DC power source available?
 - Is a vertical surface available to mount the AirLink 7032?
 - Is there enough room to open the housing door and make wiring connections?
 - Are the display screen and status lights visible?
- 2. Close and latch the housing door.
- 3. Prepare the selected mounting site as required to mount the AirLink 7032. It should be mounted at eye level (4 1/2 to 5 feet from the floor). Refer to Figure 3 for the outline and mounting dimensions.
- 4. Position the monitor on the vertical mounting surface.
- 5. Insert maximum 1/4" bolts or screws through the slots in the mounting feet at each corner of the housing to secure the housing to the mounting surface.



Figure 3: Outline and Mounting Dimensions

Wiring the AirLink 7032 Gas Monitor

This section describes procedures for DC power source wiring, AC power source wiring, Modbus out wiring, fault indicator wiring, sensor connection, and relay wiring.

The following wiring connections must be made before starting up the AirLink 7032.

CAUTION: The internal components can be static sensitive. Use caution when opening the enclosure and handling internal components.

WARNING: Make all connections to the AirLink 7032 before you plug in or turn on the AC or DC power source. Before you make any wiring adjustments, always verify that all power sources are not live.

Factory Wiring

Factory wiring for the AirLink 7032 is shown below.

NOTE: The power supply is only installed in AC versions. An AC power cord is only prewired to the power supply in AC versions ordered with a power cord.



Figure 4: Factory Wiring

Connecting a DC Power Source

NOTE: The AirLink 7032 is configured for AC or DC operation, depending on how it is ordered. If you are using AC power as the primary power source, go to the next section, "Connecting an AC Power Source".

Provide a clean and stable 22-26 VDC. Failure to do so may cause the unit (and any wired sensors that are connected to the unit) to not operate properly.

Voltage spikes higher than 26 VDC may damage the unit.

- 1. Open the enclosure box to expose the Front Panel.
- 2. Unscrew the two thumb screws on the Front Panel.
- 3. Open the Front Panel so that the Terminal Board is exposed.
- 4. Locate the Power Terminal and connect the DC-live wire (red) to the terminal marked "+12-35 VDC".
- 5. Connect the DC-ground wire (black) to the terminal marked "GND".
- 6. If desired, connect an Earth Ground wire (green) to the terminal marked "EGND" (required for surge suppression).



Figure 5: DC Wiring

- 7. Close the Front Panel.
- 8. Screw in the thumb-screws.

- 9. Close the enclosure box.
- 10. Clamp down the enclosure latches.

Connecting an AC Power Source

NOTE: The AirLink 7032 is configured for AC or DC operation, depending on how it is ordered. If you are using DC power as the primary power source, go to the previous section, "Connecting a DC Power Source".

WARNING: Verify that the power source is unplugged or turned off before you continue with this procedure.

- 1. Open the enclosure box to expose the Front Panel.
- 2. Unscrew the two thumb-screws on the Front Panel.
- 3. Open the Front Panel so that the AC (Delta) Power Supply is exposed.
- 4. The power supply is factory-wired to the Terminal Board.



5. For versions that came with a pre-wired AC line cord: there are three wires (black, white and green) pre-wired from the Delta power supply terminals "L" (AC Load IN), "N" (AC Neutral IN), and "EG" (Chassis GND or Earth GND). This set of wires will be used to plug into an AC power outlet ONCE ALL WIRING CONFIGURATIONS ARE COMPLETE.

- 6. For versions that did <u>not</u> come with a pre-wired AC line cord:
 - Connect a line wire from the AC power source to the power supply's "L" terminal.
 - Connect a neutral wire from the AC power source to the power supply's "N" terminal.
 - Connect a ground wire from the AC power source to the power supply's "EG" terminal.

NOTE: If the AirLink 7032 was not ordered with any housing holes, at least one hole will have to be drilled to bring in AC power.



Figure 6: AC Wiring

- 7. Close the Front Panel.
- 8. Screw in the thumb-screws.
- 9. Close the enclosure box.
- 10. Clamp down the enclosure latches.

RS-485 Modbus Wiring (Modbus Out)

- 1. Open the enclosure box to expose the Front Panel.
- 2. Unscrew the two thumb-screws on the Front Panel.
- 3. Open the Front Panel so that the Terminal Board is exposed.
- 4. Locate the Modbus Out Terminal Block.
- 5. Connect a red wire from a PLC's RS-485 A (+) terminal to the terminal labeled "A" on the Modbus Out Terminal Block.
- 6. Connect a green wire from a PLC's RS-485 Ground terminal to the terminal labeled "GND" on the Modbus Out Terminal Block.
- 7. Connect a black wire from a PLC's RS-485 B(-) terminal to the terminal labeled "B" on the Modbus Out Terminal Block.



Figure 7: Modbus Out Wiring

- 8. Close the Front Panel.
- 9. Screw in the thumb-screws.
- 10. Close the enclosure box.

11. Clamp down the enclosure latches.

Fault Indicator Connection

The Fault terminal provides an output to power some form of Fault indicator. The Fault terminal is wet contact, uses the same DC voltage that is powering the device, provides 500 mA maximum, and is a DC only output.

The fault terminal's fails for operation can be configured as described on page 34.

- 1. Open the enclosure box to expose the Front Panel.
- 2. Unscrew the two thumb-screws on the Front Panel.
- 3. Open the Front Panel so that the Terminal Board is exposed.
- 4. Locate the Fault Terminal Block on the terminal board.
- 5. Connect a positive (red) wire to the terminal labeled "+".
- 6. Connect a negative (black) wire to the terminal labeled "-".



Figure 8: Fault Indicator Wiring

Connecting 4-20 mA Sensors

The AirLink 7032 allows up to 32 AirLink sensor assemblies or up to 28 AirLink sensor assemblies and 4 wired 4-20 mA type sensor assemblies to be monitored (depending on the configuration ordered).

- 1. Open the enclosure box to expose the Front Panel.
- 2. Unscrew the two thumb-screws on the Front Panel.
- 3. Open the Front Panel so that the Terminal Board is exposed.
- 4. Locate the Sensor Terminal Blocks on the Terminal Board.
- 5. For each of up to 4 wired 4-20 mA type sensor assemblies:
 - Connect the sensor assembly's positive (red) wire to the terminal labeled "+VDC".
 - Connect the sensor assembly's signal (green) wire to the terminal labeled "4-20 mA".
 - Connect the sensor assembly's neutral (black) wire to the terminal labeled "GND".



Figure 9: Sensor Wiring

Relay Wiring

The AirLink 7032 has four relays. Each of the four relays may be setup as Normally Open (NO) or Normally Closed (NC). See page 48 for more explanation about relay actuation.

NOTE: If installed, the strobe is factory wired to the Relay 1 terminals and the horn is factory wired to the Relay 2 terminals.

- 1. Open the enclosure box to expose the Front Panel.
- 2. Unscrew the two thumb-screws on the Front Panel.
- 3. Open the Front Panel so that the Terminal Board is exposed.
- 4. Locate the Relay Terminal Blocks on the Terminal Board.
- 5. Connect the alarm device's "+ (H)" terminal to the **NO** or **NC** terminal on the relay terminal block.

NOTE: It is recommended that the relay connections are wired as normally-open (NO). However, normally-closed (NC) wiring configurations provide an inherent fail-safe and may be preferred.

- 6. Connect the alarm device's "- (N)" terminal to an external power source's "- (N)" terminal.
- 7. Connect the external power source's "+ (H)" terminal to the COM terminal on the relay terminal block.



Figure 10: Relay Wiring

Chapter 4: Startup and Operation

Power On/Off

Powering on the device activates its functions. When powered on, the device is fully functional and access to system and settings menus is allowed.

CAUTION: The internal components can be static sensitive. Use caution when opening the enclosure and handling internal components.

To cycle the Terminal Board power, flip the Power Switch (located on the lower right side of the Terminal Board) to the OFF (and then ON) position.



Figure 11: Power Switch Location

Home Screen

The Home screen is used to access: the trend chart, real-time values, the autoscroll setting, the Channel Configuration menu, and the Advanced Configuration menu. You can return to the Home screen from any other screen by pressing the Home button.

AirLink RK INSTRUMENTS Gas Detection for Life										
	AirLink 7032 Controller									
Soft	ware	Versi	ion 3.8 Firr	nware Ver	sion	0.0.0)			
Trend Cha	Trend Chart Real-Time Values		Autoscroll Off Cha		Cha	innel Conf	ìg			
Relay 1	Rela	ay 2 Relay 3		Relay 4 Fa		ult	Reset	t		

Figure 12: Home Screen

After 20 seconds of no button presses in the Home screen, the AirLink 7032 automatically starts scrolling through real-time values for all active channels.

Real Tim) 1 HC	OME					
Channel Status	Sensor Location	Reading	Address	Mode	Battery	TSLM	Relays
Channel 1 On		0.000	1	Normal	0.00	0	1234
Channel 2 On		0.000	2	Normal	0.00	0	1234
Channel 3 On		0.000	3	Normal	0.00	0	1234
Channel 4 On		0.000	4	Normal	0.00	0	1234
Channel 5 On		0.000	5	Normal	0.00	0	1234
Channel 6 On		0.000	6	Normal	0.00	0	1234
Channel 7 On		0.000	7	Normal	0.00	0	1234
Channel 8 On		0.000	8	Normal	0.00	0	1234
Channels 25 - 32 Channels 9 - 16						9 - 16	
Relay 1	Relay 2	Relay 3	Rela	iy 4	Fault Re		set

Trend Chart

Depending on the configuration, the AirLink 7032 can either monitor up to 32 or 64 AirLink sensor assemblies. Alternatively, the AirLink 7032 can monitor 4 wired sensor assemblies with either 28 or 60 AirLink sensor assemblies (depending on the configuration ordered).

Data from up to the past 24 hours can be viewed in the Trend Chart screen. Data is always saved to the USB drive to be viewed on a computer but data available for viewing in the Trend Chart screen gets cleared every night at midnight.

Readings for the trend chart are updated every 5 seconds.

The trend chart does not autoscroll, regardless of the Autoscroll setting on the Home screen.

- 1. If necessary, press the **Home** button to return to the Home screen.
- 2. From the Home screen, press and release the **Trend Chart** button.



3. Select the bank of channels you want to view.



4. Select the full scale range for the chart.



5. The trend chart displays.

45					
35					
30					
25					
20					C
15					
10					
5					
0	13:01:13	13:03:13	13:05:13	13:07:13	13:09:13

6. Use the buttons at the bottom of the chart to view available data.

Real-Time Values

Depending on the configuration, the AirLink 7032 can either monitor up to 32 or 64 AirLink sensor assemblies. Alternatively, the AirLink 7032 can monitor 4 wired sensor assemblies with either 28 or 60 AirLink sensor assemblies (depending on the configuration ordered).

If the instrument is in the Home screen for more than 20 seconds, it starts autoscrolling through real-time value pages, 20 seconds at a time, regardless of the Autoscroll setting.

To view real-time value pages without the pages autoscrolling, return to the Home screen, make sure Autoscroll is set to off, and manually enter the Real-Time Values screen.

- 1. If necessary, press the **Home** button to return to the Home screen.
- 2. Confirm that the Autoscroll setting on the Home screen is set appropriately.

3. From the Home screen, press and release the **Real-Time Values** button.



4. Select the bank of channels you want to view.

Real Tim	Real Time Value Channel Selection							
	Ch	annels 1-8	Channels 17	7-24				
	Cha	annels 9-16	Channels 25	5-32				
	Calibration and Zero Values							
Gas Detection for Life								
Relay 1	Relay 2	Relay 3	Relay 4	Fault	Reset			

5. The channel status, sensor location, real-time value, radio address (AirLink detector only), mode, battery level (AirLink detector only), time since last message (AirLink detector only), and relay status display.

Real Tim	G	≜HC	OME				
Channel Status	Sensor Location	Reading	Address	Mode	Battery	TSLM	Relays
Channel 1 On		0.000	1	Normal	0.00	0	1234
Channel 2 On		0.000	2	Normal	0.00	0	1234
Channel 3 On		0.000	3	Normal	0.00	0	1234
Channel 4 On		0.000	4	Normal	0.00	0	1234
Channel 5 On		0.000	5	Normal	0.00	0	1234
Channel 6 On		0.000	6	Normal	0.00	0	1234
Channel 7 On		0.000	7	Normal	0.00	0	1234
Channel 8 On		0.000	8	Normal	0.00	0	1234
Channels 25 - 3	32					Channels 9	- 16
Relay 1	Relay 2	Relay 3	Rela	iy 4	Fault	Res	set

View Days Since Last Zero and Cal

- 1. If necessary, press the **Home** button to return to the Home screen.
- 2. From the Home screen, press and release the **Real-Time Values** button.



3. Press and release the Calibration and Zero Values button.



4. The number of days since the last zero and calibration display for each channel.

Days Since Last Zero and Calibration							
Channel 1 On	Zero 0	Channel 9 Off	Zero C	Channel 17 Off	Zero C	Channel 25 Of	Zero (
	Calib 0		Calib C		Calib C		Calib (
Channel 2 On	Zero 0	Channel 10 Of	Zero C	Channel 18 Off	Zero C	Channel 26 Of	Zero (
	Calib 0		Calib 0		Calib 0		Calib (
Channel 3 On	Zero 0	Channel 11 Of	Zero C	Channel 19 Off	Zero C	Channel 27 O	Zero (
channel 5 on	Calib 0	channel II on	Calib 0	channel 19 on	Calib C	channel 27 O	Calib (
Channel 4 On	Zero 0	Channel 12 Of	Zero C	Channel 20 Off	Zero C	Channel 28 Of	Zero (
channel + On	Calib 0	channel 12 On	Calib 0	channel 20 On	Calib 0	channel 20 0	Calib (
Channel 5 On	Zero 0	Channel 12 Off	Zero C	Channel 21 Off	Zero C	Channel 30 Of	Zero (
channel 5 01	Calib 0	channel 13 Un	Calib 0		Calib 0	channel 29 Of	Calib (
Channel 6 On	Zero 0	Channel 14 Off	Zero 0	Channel 22 Off	Zero C	Channel 30 Of	Zero C
channel 6 0h	Calib 0	channel 14 Oh	Calib 0	channel 22 On	Calib 0	channel 50 Of	Calib (
al 17.0	Zero 0		Zero C	0 100 000	Zero C		Zero (
channel / On	Calib 0	Channel 15 Off	Calib 0	Channel 23 Off	Calib 0	Channel 31 Of	Calib (
	Zero 0		Zero C		Zero 0		Zero (
channel 8 On	Calib 0	channel 16 On	Calib 0	Channel 24 Off	Calib 0	Channel 32 Of	Calib (
Relay 1	Rela	ay 2	Relay 3	Relay 4	Fa	ult	Reset

Alarms

Relay indicators appear at the bottom of every screen in the AirLink 7032. The indicators turn either solid red or flash, as described below, to indicate an alarm condition.

Indicator	Color	Description
	off	No alarm condition has occurred on relay 1 since the last reset or power up
Relay 1	solid red	An alarm condition is currently happening on relay 1
	blinking red	An alarm condition has occurred on relay 1, but condition has now gone
	off	No alarm condition has occurred on relay 2 since the last reset or power up
Relay 2	solid red	An alarm condition is currently happening on relay 2
	blinking red	An alarm condition has occurred on relay 2, but condition has now gone
	off	No alarm condition has occurred on relay 3 since the last reset or power up
Relay 3	solid red	An alarm condition is currently happening on relay 3
	blinking red	An alarm condition has occurred on relay 3, but condition has now gone
	off	No alarm condition has occurred on relay 4 since the last reset or power up
Relay 4	solid red	An alarm condition is currently happening on relay 4
	blinking red	An alarm condition has occurred on relay 4, but condition has now gone
	off	No Fault condition has occurred on any sensor unit since the last reset or
Fault		power up
Taun	solid blue	A Warning condition is currently happening on at least one sensor unit
	solid orange	A Fault condition is currently happening on at least one sensor unit

Gas Alarm

The Real-Time Values screen has a column for relay status. If the reading on a particular channel has activated one of the AirLink 7032's relays, the relay number on that channel's Real-Time Values screen gets a yellow background.

For example, if Channel 1's reading activates Relay 1, the Relay 1 indicator at the bottom of the screen turns red and the "1" in Channel 1's Relays column gets a yellow background.

Real Tim		ΟΜΕ					
Channel Status	Sensor Location	Reading	Address	Mode	Battery	TSLM	Relays
Channel 1 On		10.0	1	Normal	0.00	0	<mark>1</mark> 234
Channel 2 On		0.000	2	Normal	0.00	0	1234
Channel 3 On		0.000	3	Normal	0.00	0	1234
Channel 4 On		0.000	4	Normal	0.00	0	1234
Channel 5 On		0.000	5	Normal	0.00	0	1234
Channel 6 On		0.000	6	Normal	0.00	0	1234
Channel 7 On		0.000	7	Normal	0.00	0	1234
Channel 8 On		0.000	8	Normal	0.00	0	1234
Channels 25 - 3	32					Channels	9 - 16
Relay 1	Relay 2	Relay 3	Relay 4		Fault	R	eset

1. Press **Reset** to clear an alarm indication once the alarm condition has cleared.

Fault or Warning Alarm

Press the Fault indicator from any screen to see the fault screen. Fault and warning codes are described on page 40.

Channel	Fault	Channel	Fault	Channel	Fault	Channel	Fault
1: Off	F9: Sensor Unit Radio Timeout	9: Off	No Faults	17: Off	No Faults	25: Off	No Faults
2: Off	No Faults	10: Off	No Faults	18: Off	No Faults	26: Off	No Faults
3: Off	No Faults	11: Off	No Faults	19: Off	No Faults	27: Off	No Faults
4: Off	No Faults	12: Off	No Faults	20: Off	No Faults	28: Off	No Faults
5: Off	No Faults	13: Off	No Faults	21: Off	No Faults	29: Off	No Faults
6: Off	No Faults	14: Off	No Faults	22: Off	No Faults	30: Off	No Faults
7: Off	No Faults	15: Off	No Faults	23: Off	No Faults	31: Off	No Faults
8: Off	No Faults	16: Off	No Faults	24: Off	No Faults	32: Off	No Faults
Rela	ay 1 Re	elay 2	Relay 3	Relay	4	Fault	Reset

1. Press **Reset** to clear an alarm indication once the alarm condition has cleared.

Chapter 5: Channel Configuration Menu

Overview

This mode is used for: Channel Settings (On/Off, Wired/AirLink, gas, range, radio address, location), Relay Settings (On/Off, Low/High, Value, Latching/Auto Resetting), and setting the date, time, and location for the AirLink 7032.

- **NOTE:** Each channel must be set up individually but a **Duplicate Channels** button makes it easier to set up channels that have the same settings.
- **NOTE:** To save any changes and return to the Home screen at any time, press the **Home** button. The AirLink 7032 automatically saves any changes and returns to the Home screen 15 minutes after the last button press.

Entering the Channel Configuration Menu

- 1. Open the enclosure box.
- 2. If necessary, press the **Home** button to return to the Home screen.
- 3. From the Home screen, press and release the **AirLink** logo and then press and release the **Channel Config** button.

AirL	In Airl	Link 703	RK 2 Control	Gas De	RUMENTS etection for Life	Ai	rL"ir	irLink 703	2 Contro	Gas Det	EUMENTS ection for Life
Software	e Versi	on 3.8 Firr	mware Vers	sion 0.0	0.0	Software Version 3.8 Firmware Version 0.0.0					0
Trend Chart	Real-	Time Values	Autoscroll	Off	Channel Config	Trend Chart Real-Time Values Autoscroll Off Channel C			hannel Config		
Relay 1 Re	lay 2	Relay 3	Relay 4	Fault	Reset	Relay 1	Relay 2	Relay 3	Relay 4	Fault	Reset

Editing Channel Settings

- 1. Enter the Channel Configuration Menu as described above.
- 2. Select the channel bank for the channel you want to set up.

Channel	Channel Configuration Selection						
		Ch	annels 1-8	Channels 17	7-24		
	Channels 9-16 Channels 25-32			5-32			
		Se	et Monitor Time	Date and Locati	on		
INSTRUMENTS Gas Detection for Life							
Relay 1	Rela	iy 2	Relay 3	Relay 4	Fault	Reset	

3. Select the channel you want to set up.

Channel	Config		G	▲ HOME				
Channel 1			hannel 2	Channel 3		c	Channel 4	
Channel	5	c	hannel 6	Channel 7		С	Channel 8	
Gas Detection for Life								
Relay 1	Rela	ay 2	Relay 3	Relay 4	Fa	ult	Reset	

4. The channel settings screen appears.

Channel 1 Co	onfiguration				ME	Channel 31 C	onfiguratio	n		
Channel On	Relay 1 On	Relay 2 On	Relay 3 On	Relay 4 On		Channel On	Relay 1 On	Relay 2 On	Relay 3 On	Relay 4 On
L.	Alarm On Increasing	Alarm On Increasing	Alarm On Increasing	Alarm On Increasing			Alarm On Increasing	Alarm On Increasing	Alarm On Increasing	Alarm On Increasing
	Auto Resetting	Auto Resetting	Auto Resetting	Auto Resetting		Wired Sensor	Auto Resetting	Auto Resetting	Auto Resetting	Auto Resetting
Relay Values	5.000	10.000	15.000	20.000		Relay Values	5.000	10.000	15.000	20.000
Radio Address	1 Senso 1 Locatio	or on		Duplicate Settings		Gas Type Scale	Sens Locat	ion ———		Duplicate Settings
Relay 1 R	telay 2 Rel	ay 3 Rela	y 4 Faul	t Reset	8	Relay 1 Re	elay 2 Rel	ay 3 Rela	iy 4 Fau	t Reset
	AirL	ink chann	el				V	Vired chan	nel	

5. Set up the channel. The parameters are described below.

Parameter	Description
Channel On/Off	<u>On</u> : Channel is active and attempting to connect to a detector. <u>Off</u> : Channel is inactive and not attempting to connect to a detector.
Wired/AirLink Sensor (only for channels 29- 32 or 61-64, depending on the configuration ordered)	 <u>Wired</u>: 4-20 mA type detector is wired into the Sensor Terminal Blocks on the Terminal Board. <u>AirLink</u>: Detector is communicating with the AirLink 7032 wirelessly. Any 4-20 mA type detectors wired directly to the AirLink 7032 must be set up on the following channels: <u>For 32-channel versions</u>: Channels 29-32 <u>For 64-channel versions</u>: Channels 61-64 NOTE: If a repeater is used to connect any AirLink sensors to the monitor, then all AirLink sensor connections must be routed through the repeater; there cannot be a combination of AirLink sensors making direct radio connection to a monitor while other AirLink sensors make radio connection to the monitor through a repeater.
Relay On/Off	<u>On</u> : Relay will activate when the selected channels' reading reaches the value shown in Relay Value. <u>Off</u> : Relay will not activate for the selected channel.
Alarm On Increasing/Decreasing	<u>Increasing</u> : Relay will activate if the selected channel's reading rises above the value shown in Relay Value. <u>Decreasing</u> : Relay will activate if the selected channel's reading falls below the value shown in Relay Value.
Auto Resetting/Latch- ing	<u>Auto Resetting</u> : Once the alarm condition clears, the AirLink 7032 automatically resets the alarm indications. <u>Latching</u> : Once the alarm condition clears, you must press the Reset button to reset the alarm indications.
Relay Values	Gas reading at which the relay will activate. For wired detectors, the full scale value must be set before you can define relay values.
Gas Type Scale (for wired detectors only)	Define the target gas and full scale value for the selected chan- nel. Available target gases are: H2S, SO2, O2, CO, Cl2, CO2, LEL,VOC, FEET, HCl, NH3, H2, CLO2, HCN, F2, HF, CH2O, NO2, O3, INCHES, Gas 4-20, None, Celcius, Fahren- heit, CH4, NO, PH3, HBr, EtO, CH3SH, AsH3, R410A, R1234YF, R32
Radio Address (for AirLink channel only)	Enter the radio address of the detector assigned to this channel.

Parameter	Description							
Sensor Location	Enter a 10-character name that defines where the detector is installed.							
Duplicate Settings	Duplicates settings on all subsequent channels with the excep- tion of the radio address (increments by 1) and the location.							
NOTE: If the 4th relay is not appear in this screen.	NOTE: If the 4th relay is set as a fault relay in the Advanced Configuration Menu, it will not appear in this screen.							

Changing the Date, Time, and Location

- 1. Enter the Channel Configuration Menu as described on page 29.
- 2. Press and release Set Monitor Time Date and Location.

Channel	Channel Configuration Selection							
	с	hannels 1-8	Channels 17	7-24				
	Channels 9-16 Channels 25			5-32				
	1 5	Set Monitor Time	Date and Location	on				
			STRUMENTS s Detection for Life					
Relay 1	Relay 2	Relay 3	Relay 4	Fault	Reset			

3. Type in the AirLink 7032's location and the current date and time.

Configura	Configuration									
Monitor Location (50 Characters Maximum)										
CENTRAL RIG										
The location value entered here and the monitor serial number are saved to the USB drive.										
Monitor Ti	me and Da	te Setting	5							
Month: <u>6</u> Hours: <u>14</u>	Day: <u>9</u> Minutes: _	Please note: The time is in 24 hour format Ex. 6 a.m. would be "6" Ex. 6 p.m. would be "18"								
Relay 1	Relay 2	Relay 3 Relay 4 Fault Rese								

4. Press the **Home** button to save the settings and return to the Home screen.

Exiting the Channel Configuration Menu

Complete the following steps to exit the Channel Configuration Menu at any time.

- 1. Press the **Home** button.
- 2. Close the enclosure box.
- 3. Clamp down the enclosure latches.

NOTE: The AirLink 7032 automatically saves any changes and returns to the Home screen 15 minutes after the last button press.

Chapter 6: Advanced Configuration Menu

Overview

This mode is used to: restore factory default settings, set up global Modbus parameters, set up AirLink parameters, adjust the failsafe setting for the relays, and assign Relay 4 to be a fault relay. This mode is also used to perform a calibration. See page 37 for calibration instructions.

Editing Advanced Configuration Parameters

You only have 30 seconds at a time to edit the parameters in the Advanced Configuration menu. It is recommended that you review each setting beforehand and decide what changes you want to make before starting to edit the parameters.

- 1. Open the enclosure box to expose the Front Panel.
- 2. Tap the AirLink logo then press and hold the RKI logo for 5 seconds.



3. The base layer of the Advanced Configuration Menu appears.

Configu	ration Se	ttings				▲ HOME			
Monito	or Serial #	RG00000 Dat	e Manufac	tured:	00/00/	0000			
	Reset 7032	Modbus Address	0	Relay Settings		IS			
		Modbus Baud Rate	-	Relay 1	Not Fails	afe			
	Enter	Radio Timeout	0	Relay 2	Not Fails	afe.			
	Mode	(Minutes)	U	Relay 3	Not Fails	afe.			
	Test	Gen II 900 MHz Radio Settings		Relay 4	Not Fails	afe			
	Relays	Network ID	0	Fault	Not Fails	afe			
	Restart AirLink 7032	Primary Mor	nitor	Relay 4 is Fault Relay	No				
Relay 1 Relay 2		Relay 3 Relay 4		Fault		Reset			

4. Press Restart AirLink 7032.

Config	uration Se	ettings				HOME		
Monitor Serial # RG00000 Date Manufactured: 00/00/0000								
	Reset 7032 to Factory Defaults?	Modbus Address	0	Relay	<u>js</u>			
		Modbus Baud Rate	-	Relay 1	Not Fails	safe		
	Enter	Radio Timeout	0	Relay 2	Not Fails	safe		
	Mode	(Minutes)	U	Relay 3	Not Fails	safe		
	Test	Gen II 900 MHz Ra	Relay 4	Not Fails	safe			
	Relays	Network ID	0	Fault	Not Fails	safe		
	Restart AirLink 7032	Primary Mo	Relay 4 is Fault Relay	No				
		RKI	STRUMENTS s Detection for Life			_		
Relay 1	Relay 2	Relay 3	Relay 4	Fa	ault	Reset		

- 5. Press **OK** in the window that pops up.
- 6. A message appears that says **Control Board: No Response**. Press **Close** or ignore the message.
- 7. All parameters become available for editing for <u>30 seconds only</u>. After 30 seconds, the AirLink 7032 returns to the Home screen.

Configuration Settings									
Monit	Monitor Serial # RG00000 Date Manufactured: 00/00/ 0000								
	Reset 7032	Modbus Address	Modbus Address 10		Relay Settings				
	Defaults?	Modbus Baud Rate	9600 -	Relay 1	Not Fails	afe			
	Enter	Radio Timeout	0	Relay 2	Not Fails	safe			
	Mode	(Minutes)	U.	Relay 3	Not Fails	safe			
	Test	Gen II 900 MHz Ra	Relay 4	Not Fail	safe				
	Relays	Network ID	5	Fault	Not Fail:	safe			
	Restart AirLink 7032	Primary Mo	Primary Monitor		No				
Cas Detection for Life									
Relay 1 Relay 2		Relay 3	Relay 4	Fa	ault	Reset			

8. Edit the desired parameters. They are described below.

Parameter	Description
Reset AirLink 7032 to	Sets the AirLink 7032 back to factory defaults, listed below.
Factory Defaults?	• Channels 1-28 or 1-60 set to AirLink (depending on the configuration ordered)
	• Channels 29-32 or 61-64 set to Wired (depending on the configuration ordered)
	• Relays set at "10, 15, 20 and 25"
	• All relays set to "Auto Resetting" / "Increasing"
	Modbus Output Baud set at 9600
	Radio Timeout set to 10 minutes
	• Network ID set to 5
	Primary Monitor
	Press OK to confirm the reset.

Parameter	Description
Modbus Address	Type in a Modbus address (1-247) for the AirLink 7032's Modbus output.
Modbus Baud Rate	Select a baud rate for the AirLink 7032's Modbus output. Available choices are: 1200, 2400, 4800, 9600 (factory setting), and 19200.
Radio Timeout	The Radio Timeout is the amount of time (between 6 and 255 minutes) that must pass after a AirLink detector loses connection with the AirLink 7032 before the AirLink 7032 shows an F9 fault code for that channel.
Network ID	Type in the system's network ID (between 1 and 52 for 900 MHz systems or between 1 and 78 for 2.4 GHz systems). All monitors and sensor assemblies <u>must</u> have the same Network Channel in order to communicate.
Primary/Secondary	Select the Primary/Secondary status for the AirLink 7032 (fac- tory setting is Primary).
	There can only be one Primary monitor on a network. All other monitors must be set up as Secondary monitors.
	If an AirLink 7032 is set as a Secondary monitor when there is no Primary monitor, the AirLink 7032 will go into an F15 fault.
Relay 1, 2, 3, and 4 Failsafe Settings	Independently set the 4 relays to Failsafe or Not Failsafe. See page 48 for more description about relay operation.
Relay 4 Fault Relay	Yes: Relay 4 acts as a fault relay and cannot be assigned to a gas alarm. No: Relay 4 does not act as a fault relay and can be assigned to a gas alarm.

9. After 30 seconds, the AirLink 7032 automatically saves any changes and returns to the Home screen. If you need to change additional settings, repeat Step 2 - Step 8.

Chapter 7: Maintenance

Calibration Mode

Entering Calibration Mode disables the relays and allows the sensors to be calibrated without triggering alarms. Once in Calibration Mode, the unit will remain there for two hours—unless you press the Calibration Mode Active or Home button.

- 1. Open the enclosure box to expose the Front Panel.
- 2. Tap the **AirLink** logo then press and hold the **RKI** logo for 5 seconds to enter the Advanced Configuration Menu.



3. Press Enter Calibration Mode.



4. Once in Calibration Mode, the screen appears as shown below.

Config	juration Se	ttings			1	HOME
Mor	Monitor Serial # RG00000 Date Manufactured: 00/00/0000					0000
	Reset AirLink	Modbus Address	0	Relay Settings		s
	Defaults?	Modbus Baud Rate	•	Relay 1	Not Fails	afe
	Calibration	Radio Timeout (Minutes)	0	Relay 2	Not Fails	afe
	Active		U	Relay 3	Not Fails	afe
	Test	Gen II 900 MHz Ra	dio Settings	Relay 4	Not Fails	afe
	Relays	Network ID	0	Fault	Not Fails	afe
	Restart	Primary Monitor		Relay 4 is Fault	No	
	AirLink 7032			Relay		
	CAS Detection for Life					
	C/	ALIBRATION N	IODE			Reset

5. Press Calibration Mode Active to return to the Advanced Configuration screen.

6. Press the Home button to return to the Home screen.

NOTE: The AirLink 7032 automatically returns to the Home screen 15 minutes after the last button press.

- 7. Close the enclosure box.
- 8. Clamp down the enclosure latches.

Relay Test Mode

Relay Test Mode activates each relay and can be used to determine whether or not the relays and attached alarms are functioning properly.

- 1. Open the enclosure box to expose the Front Panel.
- 2. Tap the AirLink logo then press and hold the RKI logo for 5 seconds.



NOTE: If **Calibration Mode Active** is not pressed, the unit will remain in Calibration Mode for two hours and then it will start autoscrolling through the Real-Time Values for active channels.

3. Press Test Relays.

Config	Jura	ation Se	ttings				HOME
Mon	Monitor Serial # RG00000 Date Manufactured: 00/00/ 0000						
	R	Reset 7032 Modbus Address 0			Relay	Relay Settings	
	(Modbus Baud Rate	• •	Relay 1	Not Fails	safe
	Enter		Radio Timeout	0	Relay 2	Not Fail	safe
	Mode (Minute	(Minutes)	utes) U	Relay 3	Not Fails	safe	
	_	Test	Gen II 900 MHz R	adio Settings	Relay 4	Not Fails	safe
	~	Relays	Network ID	0	Fault	Not Faile	safe
	Ai	Restart irLink 7032	Primary M	onitor	Relay 4 is Fault Relay	No	
	Cas Detection for Life						
Relay 1		Relay 2	Relay 3	Relay 4	Fault R		Reset

4. Starting with Relay 1, the relays will activate in 5-second intervals. The corresponding relay indicator along the bottom of the screen will turn red when the relay activates.

Config	Configuration Settings						
Mon	Monitor Serial # RG00000 Date Manufactured: 00/00/ 0000					0000	
	Reset AirLink	Modbus Address	Modbus Address 0		Setting	gs	
	Defaults?	Modbus Baud Rate	-	Relay 1	Not Fails	safe	
	Enter	Radio Timeout	Radio Timeout		Not Fails	safe	
	Mode	(Minutes)	U	Relay 3	Not Fails	safe	
	Testing	Gen II 900 MHz Ra	dio Settings	Relay 4	Not Fails	safe	
	Relays	Network ID	0	Fault	Not Fails	safe	
	Restart AirLink 7032	Primary Mo	Primary Monitor		No		
	INSTRUMENTS Ges Detection for Life						
Relay 1	Relay 2	Relay 3	Relay 4	Fault		Reset	

- 5. 5 seconds after the 4th relay is activated, all relays return to their normal state and **Test Relays** is no longer selected.
- 6. Press the **Home** button to return to the Home screen.

NOTE: The AirLink 7032 automatically returns to the Home screen 15 minutes after the last button press.

- 7. Close the enclosure box.
- 8. Clamp down the enclosure latches.

Troubleshooting

Table 2 describes symptoms, probable causes, and recommended actions for the most common problems you may encounter with the AirLink 7032.

NOTE: This troubleshooting guide describes <u>AirLink 7032</u> problems only. See the detector head operator's manuals for preventive maintenance procedures that apply to the detector heads installed on your AirLink 7032.

Condition	Probable Causes	Recommended Action
Two Primary Monitors	 The AirLink 7032 was setup to be a primary monitor but was turned off or reset so the secondary monitor became the primary monitor. A primary monitor already exists on the network and is conflicting with the AirLink 7032's default as primary monitor. 	1. Turn off the other monitor on the network or make sure that only one of the monitors is set up to be the primary monitor.
All Channels Turned Off	Autoscroll is turned on but all channels are turned off.	1. Turn on and set up all necessary channels as described on page 29.
Temperature Warning (for IR detector heads only)	The sensor is undergoing a rapid tempera- ture change, resulting in the potential loss of accuracy.	1. Once the sensor element temperature has stabilized, the warning will clear.
F1 (Only for AirLink T3A/ AirLink VOC Pro)	The top card has lost communication with the digital sensor board (the board potted into the sensor housing).	 Check the connections and/or try new digital sensor board.
F3 (battery powered detector only)	The Low Power IR sensor is beyond repair.	1. Replace the IR sensor.

Table 2: Troubleshooting the AirLink 7032

Condition	Probable Causes	Recommended Action
F4	 The top card is losing communication to the analog sensor board On AirLink T3A/AirLink VOC Prounits, F4 means that the Analog to Digital Conversion (ADC) on the analog sensor board is not communicating to the digital sensor board. On the AirLink 6900, F4 means the top card is not communicating with the analog sensor board. For IR sensors, the sensor element itself could be the issue. Also, there might not be an issue because sometimes sensor assemblies will show F4 for a few seconds after boot up. This is normal and is due to the boot up of the sensor element itself. 	 Check the orientation of the analog sensor board and/or try a new analog sensor board. Check the connections from the top card all the way to the analog sensor board. If that does not fix the fault, try replacing the analog sensor board and/or the sensor housing.
F5	The sensor assembly did not zero correctly.	 Confirm that no gas is present. Replace the sensor.
F6	The sensor assembly did not auto cal correctly.	 Confirm the gas concentration is correct and that it is flowing to the sensor. Replace the sensor.
F8	 There are 2 sensor assemblies with the same address trying to communicate with the monitor. There is a combination of AirLink sensors making direct radio connection to the monitor and AirLink sensors with radio connection routed through a repeater. 	 Make sure all sensor assemblies have unique addresses. If a repeater is part of the AirLink system, all AirLink sensor radio connections to the monitor must be routed through the repeater.
F9	The monitor has not received a communi- cation from the faulting sensor assembly address for the timeout period set on page 34.	1. Check the sensor assembly for a dead battery, broken antenna, bad antenna cable, missing antenna, obstacle, weather, etc.
F10 (4-20 mA wired detector only)	When using a monitor with wired sensor assemblies attached, the sensor is not communicating with the monitor. The problem could be that the sensor assembly is not connected properly, or there may be board issues with the sensor or monitor.	 Check all connections. Use a current meter inline to see if the current is correct.

 Table 2: Troubleshooting the AirLink 7032 (Continued)

Condition	Probable Causes	Recommended Action
F11 (battery powered detector only)	The IR sensor is changing temperature too quickly.	 The sensor will clear once the temperature stops changing too quickly.
F13 (4-20 mA wired detector only)	When using a monitor with a 4-20mA wired connection, F13 may appear when the sensor assembly is in a fault condition.	1. Since it is 4-20mA, the monitor does not know the exact fault condition. Therefore, check the sensor assembly to see what the fault is and then consult other items in this chart for a solution.

 Table 2: Troubleshooting the AirLink 7032 (Continued)

Chapter 8: Viewing Log Files

- 1. Download and install the EZWare-5000 converter software, found here: <u>https://www.maplesystems.com/General/DownloadFile?s=sw&n=EZware-5000%20v4.65.16&f=ez5000setup.zip</u>
- 2. Remove the SD card with USB adapter from the AirLink 7032.
- 3. Plug the SD card with USB adapter into an available port.
- 4. Use Windows Explorer to view the contents of the SD card.



- 5. There are folders for each channel's: address, battery voltage, interval data (logged every 5 seconds), fault code(s), time since last message, days since last null, days since last cal, and received signal strength indicator. There are also folders for the monitor location and the monitor serial number. Each folder contains .dtl files of data. The .dtl files must be converted to Excel files using Easy Converter before the data can be viewed.
- 6. In some cases, double clicking a .dtl file will open Easy Converter and convert the file to a .xls file.

- 7. If double-clicking the .dtl file does not automatically convert it to a .xls file:
 - a. Open Maple Systems\Easy Converter from the Start menu.
 - b. Click the **Open** button.

🕼 Untitled - EasyConverter		×
<u>F</u> ile Edit View <u>H</u> elp		
🗃 🚺 🗃 🔢 🖶 🦹 🦹 Language 1	\sim	
		~
Ready		1.3

c. Click Add File.

/lulti-File Management		×
Convert file list :		
	Add File	Delete File
Enable setting file		
Combine to a file		
		-
	OK	Cancel

d. Navigate to the .dtl file you want to convert.

e. Click OK.

/ulti-File Management		×
Convert file list :		
E:\Ch 1-16 TSLM\20210608.dtl		
	Add File	Delete File
Enable setting file		
Combine to a file		
	ОК	Cancel

f. The program indicates that the conversion was successful.

💯 Untitled - EasyConverter	—	×
<u>F</u> ile <u>E</u> dit <u>V</u> iew <u>H</u> elp		
🗃 🖬 🕅 📧 🖻 🦿 Language 1	~	
E:\Ch 1-16 TSLM\20210608.dtl Suc	cess!	^

8. Open converted .xls files in Excel or another spreadsheet software to view the data.

A	utoSave 🧿	off 🖪 🖌	୵ ∙ ୯ ∗ ୫	• •	د20210608	ls - Comp	atibility Me	ode 🔻	2	Search						Kimberly Co	ok KC I	⊞	_ /×
Fil	e Hon	ne Insert	Draw Pa	age Layout	Formula	s Data	Review	v View	Help	Acrobat							ß	Share 🖓	Comments
Pas	ste	Arial	~ 10 <u>1</u> ~ ⊞ ~ ,	✓ A [*] A [*]	= = = =	≡ ≫ ~ ∃ ⊡ :	8₽ V 1 🗐 N	/rap Text lerge & Cer	ter ~	General \$~%	9 58 ⊰	Condit	ional Format ting ~ Table	as Cell * Styles *	Insert Del	lete Format	$ \begin{array}{c} \Sigma & \bullet & \mathbf{A} \\ \hline \mathbf{U} & \bullet & \mathbf{Z} \\ \hline \mathbf{U} & \bullet & \mathbf{Sort} \\ \hline \mathbf{O} & \bullet & \mathbf{Filter} \end{array} $	7 0 & Find & * Select *	Analyze Data
Cli	pboard Is		Font		SI .	Al	ignment		12	Numb	ber	12	Styles		Ce	lls	Editi	ng	Analysis A
A1	A1 · I × ✓ fr Date ·																		
	Α	B	C	D	E	F	G	H	1	J	K	L	M	N	0	Р	Q	R	S 🔺
1	Date	Time M	lillisecond Ch	annel 1 Cha	nnel 2 Cha	nnel 3 Cha	nnel 4Cl	nannel 5C	hannel 6	Channel 7 C	Channel 8 C	Channel 9 (Channel 10 (Channel 11	Channel 12	Channel 13	Channel 14	Channel 15	Channel 16
2	6/8/2021	13:51:04	80	0	0	0	0	20.9	0	0	0	0	0	0	0	0	0	0	0
3	6/8/2021	13:51:09	80	0	0	0	0	20.9	0	0	0	0	0	0	0	0	0	0	0
4	6/8/2021	13:51:14	30	0	0	0	0	20.9	0	0	0	0	0	0	0	0	0	0	0
5	6/8/2021	13:51:19	60	0	0	0	0	20.9	0	0	0	0	0	0	0	0	0	0	0
6	6/8/2021	13:51:24	80	0	0	0	0	20.9	0	0	0	0	0	0	0	0	0	0	0
7	6/8/2021	13:51:29	70	0	0	0	0	20.9	0	0	0	0	0	0	0	0	0	0	0
8	6/8/2021	13:51:34	70	0	0	0	0	20.9	0	0	0	0	0	0	0	0	0	0	0
9	6/8/2021	13:51:39	40	0	0	0	0	20.9	0	0	0	0	0	0	0	0	0	0	0
10	6/8/2021	13:51:44	250	0	0	0	0	20.9	0	0	0	0	0	0	0	0	0	0	0
11	6/8/2021	13:51:49	140	0	0	0	0	20.9	0	0	0	0	0	0	0	0	0	0	0
12	6/8/2021	13:51:54	120	0	0	0	0	20.9	0	0	0	0	0	0	0	0	0	0	0
13	6/8/2021	13:51:59	210	0	0	0	0	20.9	0	0	0	0	0	0	0	0	0	0	0
14	6/8/2021	13:52:04	230	0	0	0	0	20.9	0	0	0	0	0	0	0	0	0	0	0
15	6/8/2021	13:52:09	180	0	0	0	0	20.9	0	0	0	0	0	0	0	0	0	0	0
16	6/8/2021	13:52:14	130	0	0	0	0	20.9	0	0	0	0	0	0	0	0	0	0	0
17	6/8/2021	13:52:19	210	0	0	0	0	20.9	0	0	0	0	0	0	0	0	0	0	0
18	6/8/2021	13:52:24	100	0	0	0	0	20.9	0	0	0	0	0	0	0	0	0	0	0
19	6/8/2021	13:52:29	170	0	0	0	0	20.9	0	0	0	0	0	0	0	0	0	0	0 -
.4) () () () () () () () () () (20210608	+										4						Þ
Read	ty 📧																E	1	

- 9. Reinstall the SD card with USB adapter into the AirLink 7032's USB slot.
- 10. Press **Cancel** on the message that appears on the display.

Chapter 9: Parts List

Table 3 lists the part numbers and descriptions for replacement parts and accessories offered for the AirLink 7032 Gas Monitor.

Part No.	Description
18-0107RK	Conduit hub (3/4 in.)
51-0040-RED	Strobe/horn, 20 - 28 VDC, Cl. I Div. 1 Zone 1
71-0560	AirLink 7032 Gas Monitor Operator's Manual (this document)

Table 3: Parts List

Appendix A: Relay Operation

Relays are offered in certain RKI devices for the purpose of activating alarms, horns, and other equipment upon the detection of gas.

There are two key terms to remember when using relays.

- Deactivated: refers to a relay in its normal state
- Activated: refers to a relay in an alarm state

"Dry" Contact and "Wet" Contact Relays

In regards to power, there are two types of relays.

- 1. Dry Contact Relays: This type of relay <u>does not</u> provide power to the equipment attached to it (i.e. if there is a light hooked up to this type of relay, it must be powered by another source).
- 2. Wet Contact Relays: This type of relay <u>does</u> provide power to the equipment attached to it (i.e. if a light was hooked up to this type of relay, it would be powered by the relay). When using a Wet Contact Relay, power should run through the "COMM" terminal to the end equipment.



Figure 13: "Dry" Contact Relay Configured as a "Wet" Contact

Failsafe Setting's Effect on Normally-Open/Normally-Closed Contacts

If Failsafe is set to No, the relays are de-energized in normal operation and energize when the appropriate alarm circuit is activated. The NO (normally open) relay contacts are open during non-alarm operation and close when the appropriate alarm condition occurs. The NC (normally closed) relay contacts are closed during non-alarm operation and open when the appropriate alarm condition occurs.

If Failsafe is set to Yes, the relays are energized in normal operation and de-energize when the appropriate alarm circuit is activated. The NO (normally open) relay contacts are closed during non-alarm operation and open when the appropriate alarm condition occurs. The NC (normally closed) relay contacts are open during non-alarm operation and close when the appropriate alarm condition occurs.



Figure 14: Relay Circuit Schematic

Appendix B: Introduction to 4-20 mA Current Loop Signals

This appendix is only an introduction. The information should serve as a brief overview of 4-20 mA current loop signal ranges and should not be considered a complete reference for proper implementation or use.

Industry standards pertaining to 4-20 mA current loop signals and other aspects of electronics are assumed to be known by the technician. For proper connection to a controller or Programmable Logic Controller (PLC), refer to the manufacturer's specific manual or instructions for that device.

Overview

When using 4-20 mA wired output signal devices, the 4-20 mA defines the current loop analog signal range, with 4 mA representing the lowest end of the range and 20 mA the highest. The relationship between the current loop and the gas value is linear. In addition, the AirLink 7032 uses values below 4 mA to indicate special status conditions, as shown below:

Current	Detector Status
2.5 mA	Sensor Fault
3 mA	Sensor in Menu Mode
3.5 mA	Sensor in Calibration Mode

Table 4: 4-20 mA Ranges

The 4 mA allows the receiving controller/PLC to distinguish between a zero signal, a broken wire, or an unresponsive instrument. Benefits of 4-20 mA convention are that it is: an industry standard, low-cost to implement, can reject some forms of electrical noise, and the signal does not change value around the "loop" (as opposed to voltage). The key advantage of the current loop is that the accuracy of the signal is not affected by a potential voltage drop in the interconnected wiring. Even with significant resistance in the line, the AirLink 7032 will maintain the proper current for the device, up to its maximum voltage capability.

Only one current level can be present at any time. Each device that operates via a 4-20 mA current loop signal must be wired directly to the controller. Units that are wired in a daisy chain configuration for the 4-20 mA current loop signal will not properly transmit data communications to the controller.

Calculations

$$I_{(4-20)} = \left(\frac{(16)(\text{value})}{\text{scale}}\right) + 4$$

I(4-20) = Current of loop, measured in mA value = ppm (or %) of gas concentration scale = full scale of sensor

Measuring Current

If the value measured is 0 mA, then: the loop wires are broken, the sensor assembly is not powered up, the sensor assembly is malfunctioning, or the controller is malfunctioning. A digital multi-meter (DMM), or current meter, may be used in conjunction with the controller and/or to test the 4-20 mA current loop signal. To measure the current, place the meter probes in line with the current loop.

Appendix C: RS-485 Modbus Output

Modbus Terms

Modbus: RTU Setting: Baud Rate = 9600 Data Bits: 8 Parity: None Stop Bits: 1 Time Out: 1000 ms Device Address: 1-247 Data Type: Holding Registers Start Address: The first register the user would like to view (must be between 1-255) Length: Depends on the number of addresses the user would like to view Scan Rate:1000 ms Data Format: Hex, Decimal, Float

Register Map

The Modbus register maps for 32 and 64-channel versions (applicable to RS-232, RS-485, and USB outputs) of the AirLink 7010 are accessible from the following URLs:

- 32-channel version: <u>https://www.rkiinstruments.com/pdf/airlink_7032-32-regmap.pdf</u>
- 64-channel version: <u>https://www.rkiinstruments.com/pdf/airlink_7032-64-regmap.pdf</u>