1. Install GX6000PID

2. Connect IrDA cable to PC, activate GX6000PID.exe. (The window below comes up.)



3. Input password (1994) and click OK. The window below comes up.



4. Turn on GX-6000 and connect by IrDA.
(When IrDA connection is done successfully, the red mark at the left bottom will light.)



5. Click Upload button. PID list is uploaded to flash memory of GX-6000.
During uplaoding, the window below comes up, it will complete for approx 3 minutes.

6. The window below comes up once uploading is done successfully.

7. Turn off GX-6000 (click Detector off button), and turn it on again.
You can now select gas from PID list in DISP mode.