## IrDA Cable Driver Installation Guide

Document Part Number: 71-0658

Revision: P1

Released: 2/1/24

- 1. Navigate to the RKI Instruments, Inc. website: https://www.rkiinstruments.com/
- 2. Move the cursor over **Product Resources** in the website header.
- 3. Click on **Software** from the dropdown menu.



4. Click on Portable Monitors to open the list of downloads.



5. Click on IrDA Drivers to download the program .zip folder.

Portable Moni	tors		
Program Name	unption	Version	File size
rDA Drivers	IrDA cable drivers for Part # 47-5084RK-01	6.7.6	7.2 MB
)3-Series Datalogging	Datalogging Software	04710	29 MB
3-Series User Setup	User Setup	04713	4 MB

IrDA Cable Driver Installation Instructions Page 1 of 3 6. After the .zip folder finishes downloading, open File Explorer and navigate to the **Downloads** folder.

				-		X
🕀 New - 🔏 🔲	) (à E) & ŵ	$\Uparrow$ Sort ${\scriptscriptstyle }$ $} \equiv$ View ${\scriptstyle }$				
$\leftarrow$ $\rightarrow$ $\checkmark$ $\uparrow$ $\checkmark$ $\checkmark$	This PC > Downloads	~	C			Q
🛓 Downloads 🛛 🖈	Name	Date modified	Туре	Size		
E Desktop 🖈	✓ Today (1)					- 1
b Creative Cloud Files	Drivers.zip 📴 CP210x_Windows_Drivers.zip	1/31/2024 8:43 AM	Compressed (zipp	7,00	1 KB	
<ul> <li>OneDrive</li> </ul>						
This PC						
E Desktop						
Documents						
Music						
Pictures						
Videos						
93 items						= 🗆

7. Right-click on the folder and select **Extract All** or open the folder. A prompt will appear. Enter the desired location for saving the extracted files.

CP210x_Windows_Drivers.z	ip	-		$\times$
(†) New -	🚺 🛅 🖻 🖻 🕅 🏷 Sort -> 🗮 View -> 🔂 Extract all 🗲			
$\leftrightarrow$ $\rightarrow$ $\checkmark$ $\uparrow$	> This PC > Downloads > CP210x_Windows_Drivers.zip			م
Downloads	Extract Compressed (Zipped) Folders	Passwo	ord p	Size
Creative Cloud Files	Select a Destination and Extract Files	No		
This PC	Files will be extracted to this folder: C\Users\ \Downloads\CP210x_Windows_Drivers Browse	No No		
Desktop	Show extracted files when complete	No No		
		No No		
Pictures				
OS (C:)				
9 items				
	Extract Cancel			

8. A new window will appear, displaying the newly extracted files in the location entered in the previous step. Double-click on the appropriate .exe file for your computer to begin installation.

## IrDA Cable Driver Installation Guide

Document Part Number: 71-0658

Revision: P1

Released: 2/1/24

9. Proceed through the on-screen installation process using the driver installer.



10. Click Finish to exit the installer.