

# DIRECT CONNECT SENSORS



NH3 Sensor



Explosion Proof  
O2 / H2S / CO



Explosion Proof  
LEL



Explosion Proof  
IR LEL & CO2



## Available gases include

- LEL, H2S, CO, & CO2
- Toxic sensors include NH3, AsH3, HCN, PH3, and SO2

## Infrared sensor for combustibles and CO2

## Patented water repellent sensor coating

## Explosion proof construction

## Optional stainless steel junction box

The RKI Direct Connect series gas sensors are highly reliable and very cost effective for the detection of common gas hazards. The direct connect series are available for LEL, H2 Specific LEL, LEL IR, Oxygen, H2S, CO, CO2, and for a variety of toxic gases. The sensors for LEL, H2, Oxygen, H2S, CO2, and Carbon Monoxide are explosion-proof with flame arrestors, and approved for use in hazardous areas (Class I, Div. 1 Groups B, C, D). An optional non-explosion proof version is available for oxygen, H2S, CO, and CO2 for use in non-hazardous atmospheres.

The Direct Connect sensors can be used in two different ways. The sensors can be mounted directly to the controllers as a complete stand alone system, or they can be mounted to explosion proof junction boxes for remote detection.

The toxic sensors are electrochemical type plug-in sensors, which provide high specificity, fast response, and long life. The plug-in design allows quick replacement in the field with no tools required. Toxic sensors are designed for use in Class I, Div. 2 hazardous locations. Sensors are available for NH3, SO2, PH3, AsH3, and HCN.

The Direct Connect sensors can be used either indoors or outdoors. The flame arrestors for the explosion-proof versions utilize a patented coating which make them water repellent. Also, splash guards are available for use in very wet environments. An optional stainless steel junction box is available for corrosive environments.



All of the Direct Connect sensors are designed to specifically interface with RKI Beacon 110, 200, and 410 controllers.

World Leader In Gas Detection & Sensor Technology



RKI Instruments, Inc. | 33248 Central Ave. Union City, CA 94587 | Phone (800) 754-5165 | (510) 441-5656 | Fax (510) 441-5650

[www.rkiinstruments.com](http://www.rkiinstruments.com)

# Explosion Proof

	LEL General Purpose	LEL H2 Specific	O2 Oxygen	H2S Hydrogen Sulfide	CO Carbon Monoxide	CH4 Methane	HC Hydrocarbons	CO2 Carbon Dioxide
 <b>Sensor With J-Box</b>	61-1000RK	61-1001RK	65-2515RK	65-2427RK-05	65-2437RK-05	61-1003RK-CH4	61-1003RK-HC	61-1004RK-02 61-1004RK-03 61-1004RK-05 61-1004RK-10
	61-1000RK-05	61-1001RK-05						
<b>Sensors</b>	Catalytic		Galvanic cell	Electrochemical		Infrared		
 <b>Sensor Only</b>	61-0140RK (UL) 61-0140RK-05 (CSA)	LEL H2 - NC-6205-01	65-2514RK	65-2428	65-2438	61-0190RK-CH4	61-0190RK-HC	61-0191RK-02 61-0191RK-03 61-0191RK-05 61-0191RK-10
<b>Measuring Range</b>	0-100% LEL		0-25% Vol.	0-100 ppm	0-300 ppm	0-100% LEL	0-100% LEL	-02 0 - 5000 ppm -03 0 - 5.0% Vol. -05 0 - 50% Vol. -10 0 - 100% Vol.
<b>Lower Detectable Limit (LDL)</b>	2% of full scale		0.1% Vol.	2% of full scale				
<b>Response Time (T-90)</b>	LEL - 30 Seconds	LEL H2 - 20 Seconds	20 Seconds	35 Seconds		30 Seconds	30 Seconds	30 Seconds
<b>Accuracy</b>	+/- 5% of full scale (0.5% volume for oxygen)							
<b>Life Expectancy</b>	2 to 3 years with normal service	3 to 5 years with normal service	2 to 3 years with normal service			5 years plus with normal service		
<b>Operating Environment</b>								
<b>Location</b>	Indoor or outdoor. Explosion proof for Class I, Groups B, C, and D atmospheres.							
<b>Temperature</b>	-40°F to 167°F -40°C to 75°C		-4°F to 113°F -20°C to 45°C	-40°F to 104°F -40°C to 40°C	23°F to 104°F -5°C to 40°C	-40°F to 122°F -40°C to 50°C		
<b>Humidity</b>	0 - 99% RH non condensing							
<b>Housing</b>								
<b>Housing J-Box</b>	Cast aluminum, explosion-proof, optional stainless steel J-box available							
<b>Sensor</b>	Stainless steel, explosion-proof							
<b>Approvals</b>	61-1000RK UL	61-1001RK UL	CSA NRTL			c UL US		
	61-1000RK-05 CSA	61-1001RK-05 CSA						
<b>Controllers</b>	Compatible with the following controllers: Beacon 110, Beacon 200, and Beacon 410							
<b>Warranty</b>	One year materials and workmanship							

# Non Explosion Proof

	<b>O2</b> Oxygen	<b>H2S</b> Hydrogen Sulfide	<b>CO</b> Carbon Monoxide	<b>Toxics</b>	<b>CO2</b> Carbon Dioxide
 <b>Sensor With J-Box</b>	65-2497RK *65-2502RK	65-2498RK	65-2499RK	See Chart Below	61-1007RK-02 61-1007RK-03 61-1007RK-05 61-1007RK-10
<b>Sensors</b>	Galvanic cell	Electrochemical			Infrared
 <b>Sensor Only</b>	65-2494RK *65-2510RK	65-2495RK	65-2496RK	See Chart Below	61-0198RK-02 61-0198RK-03 61-0198RK-05 61-0198RK-10
<b>Measuring Range</b>	0-25% Vol.	0-100 ppm	0-300 ppm		0 - 5000 ppm 0 - 5.0% Vol. 0 - 50% Vol. 0 - 100% Vol.
<b>Lower Detectable Limit (LDL)</b>	0.1% Vol.	2% of full scale			
<b>Response Time (T-90)</b>	20 seconds or less	35 seconds or less		60 seconds or less	30 seconds or less
<b>Accuracy</b>	+/- 5% of full scale (0.5% volume for oxygen)				
<b>Life Expectancy</b>	2 years with normal service	2 to 3 years with normal service			5 years plus with normal service
<b>Operating Environment</b>					
<b>Location</b>	Indoor or outdoor, Class I, Div. 2				
<b>Temperature</b>	-4°F to 122°F -20°C to 50°C		14°F to 104°F -10°C to 40°C	-40°F to 122°F -40°C to 50°C	
<b>Humidity</b>	0 - 99% RH non condensing				
<b>Housing</b>					
<b>Housing J-Box</b>	Cast aluminum, explosion-proof				
<b>Sensor</b>	Aluminum				
<b>Controllers</b>	Compatible with the following controllers: Beacon 110, Beacon 200, and Beacon 410				
<b>Warranty</b>	One year materials and workmanship				

\* Partial pressure sensor for helium (He) applications. Consult factory for details.

<b>Toxic Sensor Transmitter Ordering Information (includes junction box)</b>			
<b>Part Number With J-Box</b>	<b>Part Number Without J-Box</b>	<b>Gas</b>	<b>Range</b>
65-2301RK-AsH3	65-2300RK-AsH3	Arsine (AsH3)	0 - 1.5 ppm
65-2301RK-NH3	65-2300RK-NH3	Ammonia (NH3)	0 - 75.0 ppm
65-2301RK-HCN	65-2300RK-HCN	Hydrogen Cyanide (HCN)	0 - 15 ppm
65-2301RK-PH3	65-2300RK-PH3	Phosphine (PH3)	0 - 1.00 ppm
65-2301RK-SO2	65-2300RK-SO2	Sulfur Dioxide (SO2)	0 - 6.00 ppm

# AVAILABLE ACCESSORIES



Flow through adaptors



Remote horns & lights



Calibration kits



Battery Backup



Calibration adaptors



Remote Calibration Adapters



Datalogger

## Direct Interface with Beacon 110 / 200 / 410 Controllers

Direct Connect Wiring Matrix		
Sensor	Number of Wires to Controller	Maximum Distance to Controller
		18 AWG wire min.
LEL / CO <sub>2</sub>	4	500 ft.
Oxygen	2	500 ft.
H <sub>2</sub> S	2	500 ft.
CO	2	500 ft.
Toxics	2	500 ft.



Made in the USA

Authorized Distributor:

