



INSTRUMENTS

82-5201-01 Email/Text Generator Operator's Manual

Part Number: 71-0556

Revision: P8

Released: 12/13/21

Product Warranty

RKI Instruments, Inc. warrants gas alarm equipment sold by us to be free from defects in materials, workmanship, and performance for a period of one year from date of shipment from RKI Instruments, Inc. Any parts found defective within that period will be repaired or replaced, at our option, free of charge. This warranty does not apply to those items which by their nature are subject to deterioration or consumption in normal service, and which must be cleaned, repaired, or replaced on a routine basis. Examples of such items are:

- a) Absorbent cartridges
- b) Pump diaphragms and valves
- c) Fuses
- d) Batteries
- e) Filter elements

Warranty is voided by abuse including mechanical damage, alteration, rough handling, or repair procedures not in accordance with the operator's manual. This warranty indicates the full extent of our liability, and we are not responsible for removal or replacement costs, local repair costs, transportation costs, or contingent expenses incurred without our prior approval.

THIS WARRANTY IS EXPRESSLY IN LIEU OF ANY AND ALL OTHER WARRANTIES AND REPRESENTATIONS, EXPRESSED OR IMPLIED, AND ALL OTHER OBLIGATIONS OR LIABILITIES ON THE PART OF RKI INSTRUMENTS, INC. INCLUDING BUT NOT LIMITED TO, THE WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. IN NO EVENT SHALL RKI INSTRUMENTS, INC. BE LIABLE FOR INDIRECT, INCIDENTAL, OR CONSEQUENTIAL LOSS OR DAMAGE OF ANY KIND CONNECTED WITH THE USE OF ITS PRODUCTS OR FAILURE OF ITS PRODUCTS TO FUNCTION OR OPERATE PROPERLY.

This warranty covers instruments and parts sold to users by authorized distributors, dealers, and representatives as appointed by RKI Instruments, Inc.

We do not assume indemnification for any accident or damage caused by the operation of this gas monitor, and our warranty is limited to the replacement of parts or our complete goods.

Table of Contents

Overview	4
Specifications	5
Installation	6
Wiring	8
Configuration	10
Entering Configuration Mode and Initial Connection	10
WiFi Configuration	12
Soft AP Configuration	13
Email Client Configuration	13
Calibration Configuration	14
Power On and Input Emails	15
Troubleshooting	17

Overview

The 82-5201-01 email/text generator is capable of monitoring 4 sets of contacts and sending out an email and/or text message when a contact opens or closes. It can also send out an email and/or text message when it is powered up.

The email/text generator is installed in a plastic housing that has a strain relief bushing on the bottom. An AC/DC power supply is installed beneath the email/text generator. The power supply's AC input terminals are wired to a terminal strip at the bottom of the mounting plate to make it easy to connect power at the installation site. The DC output wires are wired to the email/text generator's input terminals.





Figure 1: Component Location

Specifications

Input Power	9 - 12 VDC OR 110/240 VAC	
Current Draw	100 mA max	
Email Broker	SMTP (what most email brokers, such as Gmail and Outlook, use)	
WiFi	2.4 GHz * Does not support 5 GHz networks, captive portal networks, or networks whose passwords have special characters such as #\$\$%*	
Contacts	4 contact closure input ports	
LED	Flashing White	Device is trying to connect to WiFi.
	Flashing Green	Device is properly connected to WiFi and is ready for operation.
	Yellow	Device is booting up.
	Flashing Blue 1x/second	Device is in Configuration Mode and should appear as a WiFi network on your computer, phone, or tablet.
	Flashing Blue 2x/second	Device is trying to send an email and/or text.
	Flashing Random Colors	Device is restoring factory default settings.
	Single Red Flash	Email/text sending failed. It is normal for the generator to return to flashing green after 5 seconds.
	Double Red Flash	There is an issue with Device Settings. It is normal for the generator to return to flashing green after 5 seconds.
	Triple Red Flash	WiFi connection cannot be established with configured network.

Installation

1. Select the mounting site. When you select the mounting site consider the following factors:
 - Is an AC or DC power source available?
 - Is there enough room to open the housing door and make wiring connections (see Figure 2)?
2. The mounting feet and hardware to install the mounting feet are shipped in a bag inside the housing. Install the mounting feet as shown below.



3. Position the monitor on a vertical surface at eye level (4 1/2 to 5 feet from the floor).
4. Use 3/16" screws through the slots in the mounting feet at each corner of the housing to secure the housing to the mounting surface.




Figure 2: Dimensions

Wiring

1. If using AC power:
 - a. Unscrew and remove the keps nuts from the AC terminal strip's cover.
 - b. Route the AC wires through the strain relief bushing on the bottom of the housing.
 - c. Connect a line wire from the AC power source to the "H" terminal on the AC terminal strip.
 - d. Connect a neutral wire from the AC power source to the "N" terminal on the AC terminal strip.
 - e. Connect a ground wire from the AC power source to the "G" terminal on the AC terminal strip.
 - f. Reinstall the AC terminal strip's cover using the keps nuts.




Figure 3: AC Wiring

2. If using a 9 - 12 VDC power source:
 - a. Disconnect the factory-installed red and black wires from the email/text generator's input terminals.
 - b. Route the DC wires through the strain relief bushing on the bottom of the housing.
 - c. Connect the power source's "+" line to the "+" terminal on the DC terminal strip.
 - d. Connect the power source's "-" line to the "-" terminal on the DC terminal strip.





Figure 4: DC Wiring

3. Wire the 2 terminals for each Contact Closure Input to the contacts they are intended to monitor.
4. Tighten the screw on the strain relief bushing to secure the wires.
5. Turn on the power source.


Configuration

Entering Configuration Mode and Initial Connection


1. Connect power to the device. If it's the first time the device has been turned on, it will turn on in Configuration Mode and the LED will be flashing blue. If the LED is flashing green, press the Mode button on the right side of the device to switch to Configuration Mode using a tool with a 90° angle.
2. Navigate to the WiFi screen on your computer, phone, or tablet and find **NCD_Email**.
3. The password to join the network is **NCDBeast**.



4. Your device may automatically launch a browser and take you to the configuration web interface. If it does not, you may need to tap the network name again (on a phone or tablet) or type **172.217.28.1** into a Chrome, Firefox, or Safari browser window (on a computer).



5. The device's configuration web interface appears.



WiFi Configuration


The screenshot shows a mobile application interface for WiFi configuration. At the top, there is a status bar with the time 9:42, signal strength, Wi-Fi, cellular, and battery (83%) icons. Below the status bar is a header with 'Sign in to NCD_Email' and the URL 'connectivitycheck.gstatic.com'. The main content area is titled 'WiFi' and contains several input fields and a checkbox. The 'Network' field is a dropdown menu showing 'WF100_0101C4'. Below it is a 'Hidden' field. The 'Password' field is empty. The 'DHCP' checkbox is checked. The 'Enabled' checkbox is also checked. Below these are fields for 'Default' (192.168.1.1), 'Gateway' (255.255.255.255), 'Subnet' (8.8.8.8), 'Mask' (8.8.8.8), and 'DNS' (8.8.8.8). At the bottom of the form is a 'Save Settings' button. The bottom of the screen shows the Android navigation bar with three icons: a home button, a square button, and a back button.

1. Network: Select a 2.4 GHz WiFi network from the drop down menu. The device does not support 5 GHz networks.
2. Hidden Network: If your network does not appear, manually enter the 2.4 GHz network's SSID. The device does not support 5 GHz networks. Do not enter anything in the **Hidden Network** field if you selected a network from the **Network** drop down menu.
3. Password: If your network is password-protected, enter the password. The device does not support networks whose passwords have special characters such as #,\$%*. If your network is not password-protected, leave this field blank.
4. DHCP: Select the box if the network you are connecting to is a DHCP network. Deselect the box if you need to assign a static IP address.

NOTE: The rest of the fields are only active if **DHCP** is deselected.

5. Default Gateway: Enter the network's default gateway IP.
6. Subnet Mask: Enter the network's subnet mask IP.
7. DNS Primary: Enter a valid DNS primary server IP. The IP can match the network settings or it can be a common DNS server. 8.8.8.8 is the IP for Google's primary DNS lookup server.
8. DNS Secondary: Enter a valid DNS secondary server IP. The IP can match the network settings or it can be a common DNS server. 8.8.4.4 is the IP for Google's secondary DNS lookup server.
9. Static IP: Enter the static IP address that you want the device to use on your network.


Soft AP Configuration



The screenshot shows the 'Soft AP' configuration screen in the NCD Email application. The status bar at the top indicates the time is 10:48 and the battery level is 72%. The page title is 'Sign in to NCD_Email' with the URL 'connectivitycheck.gstatic.com'. The NCD logo and 'www.NCD.io' are displayed. The 'Soft AP' section contains the following fields: 'Soft AP' (Email Generator), 'SSID:' (empty), 'Soft AP' (1234), and 'Password:' (empty). Below this are sections for 'Email Client', 'Calibration', 'Power On Email', and 'Input 1 Close Email'. A 'Save Settings' button is at the bottom.

1. **Soft AP SSID:** While in Configuration Mode, the device acts as a WiFi access point and broadcasts an SSID. Enter the SSID you'd like the device to broadcast.
2. **Soft AP Password:** Enter the password you want the device to require when trying to connect to its WiFi access point.

Email Client Configuration




The screenshot shows the 'Email Client' configuration screen in the NCD Email application. The status bar at the top indicates the time is 1:51 and the battery level is 75%. The page title is 'Sign in to NCD_Email' with the URL 'connectivitycheck.gstatic.com'. The NCD logo and 'www.NCD.io' are displayed. The 'Email Client' section contains the following fields: 'Host:' (smtp.office365.com), 'Host Port:' (587), 'Login:' (redacted@rkinstruments.d), 'Email:' (empty), 'Password:' (masked with dots), 'Device:' (NCD_CC_Email), 'Name:' (empty), and 'Retries:' (5). Below this are sections for 'Calibration', 'Power On Email', and 'Input 1 Close Email'. A 'Save Settings' button is at the bottom.

1. **Host:** Enter the email broker's SMTP host address. Common addresses are smtp.gmail.com and smtp-mail.outlook.com.
2. **Host Port:** Enter the email broker's SMTP port. Most email brokers that support SMTP connection use port 587.

3. Login Email: Enter the email address you'd like to use to generate emails/texts.
4. Password: Enter the password used to access the email address entered in **Login Email**.
5. Device Name: Enter the text you want to appear in the signature of sent emails/texts.
6. Retries: Enter the number of times you want the device to attempt to send emails and/or texts if the initial attempt is unsuccessful.

NOTE: If you are going to use a Gmail address to send emails/texts, make sure the “Allow less secure apps” setting is selected in your Google account.

Calibration Configuration




1. Debounce Cycles: This setting defines how many CPU cycles are needed to determine a change in status. Most contacts bounce when they first make contact and this setting prevents those bounces from being recorded as separate events.

Do not change this setting unless recommended by RKI Instruments, Inc.

2. Input Validate: This setting defines how many milliseconds the contact must stay in a changed state before the device sends an email and/or text. The default setting is 5000 milliseconds (5 seconds).

Power On and Input Emails/Texts

The device will generate emails and/or texts when the device powers on and/or when any of the contacts close or open. You must make email/text settings for each event type (Power On, Input 1 Close, Input 1 Open, etc.) individually, even if they are all going to the same email address and/or phone number. If you don't want emails/texts sent for a particular event type, leave the fields blank.



1. **Subject:** Enter the subject title for the email/text generated from the event type. The text must be alphanumeric and cannot contain any special characters.
2. **Message Body:** Enter the body for the email/text generated from the event type. The text must be alphanumeric and cannot contain any special characters.

NOTE: The Power On message includes a WiFi signal strength percentage in addition to any entered text.

3. **Recipients:** Enter the email address(es) and/or phone number(s) you want to receive emails/texts for the event type. Separate multiple email addresses and/or phone numbers with a comma (ie. test1@test1.com,test2@test2.com). Do not add any spaces between email addresses or phone numbers. For phone numbers, you must use a XXXXXXXXXXXX@_____ format where the domain name used in the blank field depends on the number's wireless carrier.

Wireless Carrier	Domain Name
AT&T	txt.att.net (SMS) <u>OR</u> mms.att.net (MMS)
Boost Mobile	sms.myboostmobile.com (SMS) <u>OR</u> myboostmobile.com (MMS)

Wireless Carrier	Domain Name
Cricket	sms.cricketwireless.net (SMS) <u>OR</u> mms.cricketwireless.net (MMS)
Google Fi	msg.fi.google.com (SMS & MMS)
Metro PCS	mymetropcs.com (SMS & MMS)
Sprint	messaging.sprintpcs.com (SMS) <u>OR</u> pm.sprint.com (MMS)
T-Mobile	tmomail.net (SMS & MMS)
Tracfone	mmst5.tracfone.com (MMS)
U.S. Cellular	email.uscc.net (SMS) <u>OR</u> mms.uscc.net (MMS)
Verizon	vtext.com (SMS) <u>OR</u> vmpix.com (MMS)
Virgin Mobile	vmobl.com (SMS) <u>OR</u> vmpix.com (MMS)
Xfinity Mobile	vtext.com (SMS) <u>OR</u> mypixmessages.com (MMS)

Troubleshooting

Problem	Solutions
Unable to access configuration web interface	<ul style="list-style-type: none">• If the LED is not flashing blue, press the Mode button on the side of the device using a tool with a 90° angle.• Try using a different computer, phone, or tablet.• On a computer that is connected to the device, launch a Chrome, Firefox, or Safari window and type in 172.217.28.1.
LED repeatedly flashes 3 times (won't connect to WiFi network)	<ul style="list-style-type: none">• Ensure the network you are trying to connect to is a 2.4 GHz network. The device does not support 5 GHz networks.• Ensure the network password does not contain characters like #,\$%*.• Move the device to within 10 feet of the router/access point and try again.
LED repeatedly flashes twice (email/text not going through)	<ul style="list-style-type: none">• Make sure the “Allow less secure apps” setting is selected in your Google account.• Make sure the settings in the Email Client portion of the configuration web interface are correct.

NOTE: The email/text generator is a 3rd party device. Please contact NCD at <https://community.ncd.io/> for email/text generator support.
