



COLD CLIMATE PERSONAL MONITOR

Gas Detection For Life

GX-2001 Canadian Version



Worlds Smallest 4 Gas Monitor
2.8" H x 2.2" W x 1.1" D

Features

- Simultaneous detection of 4 gases LEL, O₂, H₂S and CO
- Smallest 4 gas monitor on the market 2.8" H x 2.2" W x 1.1" D, 6 oz.
- Vibration alarm
- Alarm trend data
- Self resetting alarms
- Datalogging standard
- Autocalibration
- Rechargeable NiMH battery pack
- Battery pack recharges in 90 minutes
- Continuously operates for up to 18 hours
- Large LCD display screen
- Automatic backlighting at alarm
- High impact, RFI shielded body
- STEL readouts
- Continuously displays current time
- Intrinsically safe, CSA, C / US classified
- 2 year warranty

Applications

- | | |
|------------------------------|--------------------------------|
| • Personal monitoring | • Hazardous material |
| • Confined spaces | • Water / wastewater treatment |
| • Refineries / petrochemical | • Fire services |
| • Utilities | • Mining |
| • Chemical plants | |

RKI is proud to offer the smallest 4-gas monitor in the world, the GX-2001. Weighing only 6 ounces and about the size of a pager (2.8" H x 2.2" W x 1.1" D), the GX-2001 simultaneously monitors combustibles, oxygen, carbon monoxide, and hydrogen sulfide. The GX-2001 is armed with standard features like a vibration alarm, autocalibration, datalogging, rechargeable Ni-MH battery pack, STEL readings, peak hold and auto backlighting at alarm on a large LCD display, and it even tells the time! All of these controls and features are operated through 3 simple glow in the dark buttons. Utilizing either the standard charger or datalogging / charger station, the Ni-MH battery pack will operate for 18 hours and fully recharge in 90 minutes. Also available is the datalogging software program which is Windows 95, 98, ME, and XP compatible. The GX-2001 is also compatible with the Data Cal 2000 instrument maintenance system.

The GX-2001 is designed around the world's smallest gas sensors. Utilizing catalytic combustion, electrochemical and galvanic sensor technologies, each miniaturized sensor is manufactured with the same high quality control that has made RKI sensors and instruments the most reliable and long lasting monitoring devices in the industry.

RKI Instruments, Inc. • 33248 Central Ave. Union City, CA 94587 • Phone (800) 754-5165 • (510) 441-5656 • Fax (510) 441-5650

World Leader In Gas Detection & Sensor Technology
www.rkiinstruments.com

GX - 2001 Canadian Version

Gas Detected	All Combustible Gases (Methane as standard)	Oxygen (O ₂)	Hydrogen Sulfide (H ₂ S)	Carbon Monoxide (CO)	
Detection Principle	Catalytic combustion	Galvanic cell	Electro-chemical cell		
Detection Range (Increments)	0 ~ 100% LEL (1% LEL)	0 ~ 40.0% Vol. (0.1% Vol.)	0 ~ 100.0 ppm (0.5 ppm)	0 ~ 500 ppm (1 ppm)	
Sampling Method	Diffusion sampling, standard hand aspirator or motorized pump optional				
Display	Digital LCD with 7 segments, auto backlight at alarm display automatically cycles every 3 seconds reading each gas, immediate reading for alarm condition.				
Preset Alarms (User Adjustable)	1st alarm 10% LEL 2nd alarm 20% LEL Over alarm 100% LEL	Low alarm 19.5% High alarm 23.5% Over alarm 40.0%	1st alarm 10 ppm 2nd alarm 15 ppm STEL alarm 15 ppm	1st alarm 25 ppm 2nd alarm 50 ppm STEL alarm 200 ppm	
Types of Alarms	Gas Alarm: 2 increasing alarms, STEL, overscale alarm Trouble alarm: Sensor disconnection, wire disconnection, low battery, circuit error, calibration range error				
Display of Alarm	Gas Alarm: Flashing LEDs, intermittent buzzer, flashing gas value, vibration Trouble alarm: Flashing LEDs, intermittent buzzer, display of error message				
Special Functions	Manual back light LCD (Automatic at alarm) STEL Peak hold Continuous display of current time Autocalibration		Datalogging (40 hours) Alarm trend Direct charging in just 90 minutes Self resetting alarms Auto zero at start up		
Operating Temp. & Humidity	-20° C ~ + 40°C (14 to 104°F), 0 to 85% RH, non-condensing (splash resistant)				
Response Time	Within 30 seconds (T90)				
Continuous Operation	Up to 18 hours				
Power Source	Direct charging NiMH battery pack, charges in just 90 minutes				
Safety Design / Approvals	CSA classified, "C/US", as Intrinsically Safe. Exia. Class I, Groups A, B, C, & D Class I, Zone 0, Group IIC. Temperature Code T3C, Performance certified to CSA C22.2 No. 152				
Dimension & Weight	Approx. 72 (H) x 56 (W) x 27 (D) mm (2.8" H x 2.2"W x 1.1"D), approx. 140 g (6 ounces)				
Case Material	Dust & weather resistant. RFI shielded high impact plastic and stainless steel				
Controls	Three glow in the dark buttons: POWER / MODE, DISP, AIR				
Required Accessories	Battery charger (basic charger or datalogging charger)				
Standard Accessories	Wrist strap Alligator clip (belt clip or hardhat clip also available) Protective rubber boot Ni-MH battery pack				
Optional Accessories	Neck strap (Wrist strap is standard)13-0113RK Basic charger station, 115 VAC powered49-2155RK-01 Datalogging / Charger station (IR) with cable and software for datalogging (Windows 95, 98, ME & NT)49-2156RK-01 Charger, 12 VDC, with cigarette lighter plug49-2157RK Hand aspirated sample draw with hose and probe81-1160RK Padded carrying case for GX-2001 and accessories20-0112RK-01 Data Cal 2000 calibration station81-DC2000-01 GX-2001 docking module81-DM2001				
Configurations	<ul style="list-style-type: none"> • 4 gas, LEL / O₂ / H₂S / CO • 3 gas, LEL / O₂ / H₂S • 3 gas, LEL / O₂ / CO 		<ul style="list-style-type: none"> • 2 gas, LEL / O₂ • 2 gas, O₂ / H₂S • 2 gas, O₂ / CO 		<ul style="list-style-type: none"> • 2 gas, LEL / CO • 2 gas, LEL / H₂S • 1 gas, LEL
Warranty	Two years material and workmanship				

Note:
LEL Lower Explosive Limit
PPM Parts Per Million

STEL Short Term Exposure Limit

* Specifications subject to change without notice.



33248 Central Avenue Union City, CA 94587
Toll Free: (800) 754-5165 • Phone: (510) 441-5656 • Fax: (510) 441-5650
mail4rki@rkiinstruments.com • www.rkiinstruments.com

Authorized Distributor: