

Model SP-208 (for Natural gas and city gas)

Model SP-208L (for LPG)



Features

- Flexible tapered nozzle applied
- Alarms with vibration, sound, light
- Easy to see LED of gas concentration
- Auto zero with no manual adjustment needed
- Easy to replace, long lasting sensor
- Flow check function ensures reliable detection

Specifications

MODEL	SP-208	SP-208L
Detection principle	Special catalytic/semiconductor combination sensor, with automatic sampling (pump drawn).	
Measuring range	10 ~ 1000 ppm	
Display	LED	
Response time	Within 3 seconds	
Alarm functions	Zero error, Low flow rate, Low battery voltage (ALL LED's blink.)	
Power requirements	AA size batteries (3 pieces)	
Continuous operation	Approx. 9 hrs with alkaline batteries	
Ambient temperature	-10 ~ +50°C	
Dimensions	Approx. 35(W)×128(H)×57(D)mm	
Weight	Approx. 320g	

Specifications subject to change without notice



33248 Central Avenue Union City, CA 94587
Toll Free: (800) 754-5165 • Phone: (510) 441-5656 • Fax: (510) 441-5650
mail4rki@rkiinstruments.com • www.rkiinstruments.com